

Kitchen Minder Set-up Manual



Extended Hold Bin
DHB-BKF & EHB Series



PC Minder Ver. 6.0



Kitchen Minder Ver. 6.0

Burger 90min
Upper 240 deg. F
Lower 220 deg. F



Prince Castle®
2nd Generation Food Holding Technology

TABLE OF CONTENTS

Requirements	2
Upgrading PC Minder and Kitchen Minder to 6.0.	3
Model Identification	6
Connecting and Configuring PC Translator II Kits to the Kitchen Minder.	7
Setting Bin Addresses.	9
Setting Bar Addresses.	10
Loading Product Profiles.	11
Programming Holding Bins for Kitchen Use	13
3x4 Special Instructions	15




355 EAST KEHOE BLVD. ~ CAROL STREAM, IL, 60188, USA
PHONE: 630-462-8800 ~ TOLL FREE: 1-800-PCASTLE
FAX 630-462-1460 ~ WWW.PRINCECASTLE.COM

Requirements

1 PC Minder and Kitchen Minder have version 6.01 software

Check the software on your PC Minder by clicking Help > About



The version must be v6.01.55 or higher to function with the Prince Castle Gen2 PHU's. If your version is not v6.01.55 or higher, please go to Page 3

2 New PHU's require New Prince Castle Translator II Kits

For instructions on connecting the new Prince Castle Translator II kits and configuring your New Gen2 PHU's, go to page 7

Upgrading to PC Minder and Kitchen Minder 6.0

Version 6.0 requires a valid software license and is **Included** with Kitchen Minder Systems shipped on or after March 20, 2014. Regardless of the ship date, all KM2 color units have an included license.

Kitchen Minder1 (KM1) Systems shipped prior to March 20, 2014 require a **Paid Upgrade License** upgrade.

To purchase the **Paid Upgrade license**, pay on-line at the following Kitchen Technology Innovations link : <http://shop.onkti.com/>

- 1 On the back-of-house (BOH) computer, go to www.goicc.com



Click on the Burger King icon toward the top right of the screen

- 2 Locate the correct software


Select your country by clicking on the correct flag

Find and select:

[Download v6.0 Kitchen Minder/PCMinder software](#)

- 3 Download and run the install KMSS package and click **Next** through the first four install screens, then **Install**, and then click **Finish** at the end. For upgrades, do not check the box when it asks if you want to use QES Minder. For 1st time installations, check the box. Run the new version of PC Minder.

- 4 Validate that the correct version of PC Minder is installed by clicking Help, About on the top bar. The dialogue box that pops up should say that version 6.01.55 or higher is installed.



Upgrading to PC Minder and Kitchen Minder 6.0 (cont.)

5 The BOH Computer should already be connected to the “Programming Port” of the Kitchen Minder and tested during the initial installation. See your Kitchen Minder Installation guide for details.


If you can successfully send data from PC Minder to the Kitchen Minder the connection is OK and skip to # 7.

If data transmission fails go to #6.



6 Run a communications test


A



While the Kitchen Minder is on, go to PC Minder. Under the “Tools” tab, select “Communication Test”

Enter “admin” as password when prompted.

B



In dialogue box that pops up, select “Find Serial Communications Port”

If it finds a serial communications port, it will indicate which port it found, then move to step 10.

C



If there is no port found, it will display an error message like the one shown above.

Then check the connections between the computer and the Kitchen Minder, COM Port assignments in Windows Device Manager and USB-Serial Drivers .Replace any suspect parts and test again.

Upgrading to PC Minder and Kitchen Minder 6.0 (cont.)

7 Check the software version of current Kitchen Minder unit by cycling power on the unit and observing the bottom right corner of the screen for the version number. If the version is 6.01 or higher skip to Page 6. If the version number is lower than 6.01, continue to step 8.



8 Check the version of the Kitchen Minder unit (KM1 or KM2) by looking on the back of the unit

Kitchen Minder2
 Identified by **Ethernet Port**
 and 801390 Adapter




Kitchen Minder1
 Identified by NO Ethernet Port
 and 801114 Adapter




- 9** To upgrade the Kitchen Minder unit:
- a) Return to PCMinder on the BOH computer
 - b) Go to the "Tools" menu on the top ribbon and scroll over "Device Upgrades" and select Kitchen Minder 1 or Kitchen Minder 2 depending on which version the unit is.
 - c) If prompted, enter "admin" as the password and select "OK"
 - d) When the dialogue box appears showing that there is an upgrade, select the "Reprogram" button.
 - e) Power the Kitchen Minder unit off, WAIT 10 SECONDS, and then turn it back on, then select "Continue" on-screen.
 - f) As progress is displayed, DO NOT use the computer or Kitchen Minder during the 5-10 minutes of the upgrade process.
 - g) When "Programming Complete" is shown, select the "OK" button. If this upgrade fails, repeat steps a-f. If still unsuccessful, call ICC Tech Support.
 - h) Repeat step 7 before proceeding, in order to verify correct software version on Kitchen Minder.

Model Identification

DHB-BK24AFCE



EHB24ACE



Connecting and Configuring Prince Castle Translator II Kits to the Kitchen Minder

1 Layout Bins in store

Bins may be stacked up to (4) *shelves* high, BUT ensure that all employees can reach product on the top shelf.

IMPORTANT: To prevent injury, team-lift the bins

2 Connect black power cable from the back of each holding bin to a matching grounded plug. Power unit on with green switch on front.

3 Place new Prince Castle Holding Bins on a flat surface in the location in the kitchen designated by the store manager .

Each translator II box follows the below rules for the amount of bins that can connect to one (1) translator II box.

1. One (1) 3x4 can connect to one (1) other bin of any size
2. Excluding the 3x4 bin, you can connect any three (3) bins together to one (1) translator box

Example: The store would like to setup two (2) 3x4 bins and two (2) 2x4 bins and one (1) 4x2 bin.

Setup: The store would need two (2) translator II kits. The two (2) 3x4 bins could connect together using one (1) translator II box. The remaining three (3) bins would connect together using the second translator II box.

Connecting and Configuring Prince Castle Translator II Kits to the Kitchen Minder (cont.)


4 Connect Kitchen Minder to Prince Castle Translator box (PC II Box), **PN 990198-10 is the kit part number.**

For each configuration chosen, (1) PC II Box and Ethernet is needed cable.

Connect first configuration to the Kitchen Minder by plugging one end of the Ethernet cable into the COM1 port on the back of the Kitchen Minder and the other end into the FROM KM port on the PC II Box.

NOTE: Verify that the black box says “PRINCE CASTLE TRANSLATOR II 980198-10” on the label of the box. If not, get a new box from Prince Castle or your service agency before proceeding.


Repeat this for up to (3) configurations using the COM1, COM2, and COM3 ports on the Kitchen Minder in order but ALWAYS using the KITCHEN MINDER port on the Black Box



NOTE: These and all cables are intended to be permanent, DO NOT remove them or the bins.


5 Connect to First Bin : Connect each Level Shifter to the First Bin in each configuration. Plug one end of a COM cable into the Level Shifter and the other end into the IN (white) port on the back of the First Bin.

6 String multiple bins together.
If a configuration is being used that has multiple bins, they need to be connected. This is done by connecting one end of a COM cable to the OUT (black) port of the First Bin and the other end to the IN (white) port of the Second Bin. [If (3) bins are in the configuration, you will also need to connect a COM cable between the OUT port of the Second Bin to the IN port of the Third Bin.]



Setting Bin Addresses


To allow Kitchen Minder to properly communicate with the bins, bin addresses need to be set as shown in the figure below. The figure shows all possible numbering configurations that DO NOT include 3x4 units, for those layouts, go to page 15.



Use the above numbering layout for bins, and use only the boxes necessary. The bin closest to the Kitchen Minder will ALWAYS be BIN2, the next is BIN4, and last is BIN6. The lower timer bar will match the bin number (BAR2 is the lower bar on BIN2) and the upper bar is one number greater. If only (1) or (2) bins are used, omit the higher numbers. If any bin has only (1) timer bar, omit the higher number.

Example: A 2x2 is linked to a 4x2. The 2x2 will be set to BIN2 and its bar to BAR2, the 4x2 will be set to BIN4, the lower bar to BAR4, and the upper bar to BAR5.

This is done using the control panel on the front of the unit. First, check what the current Bin Address is by pressing and holding the ACTUAL TEMP and SET-POINT buttons at the same time until the Bin Address is shown on the display. If the correct Bin Address is shown on all bins, proceed to next page step 10.



1. To change a bin address, disconnect the power to the unit. Reconnect power to the unit and immediately press and hold the **ACTUAL TEMP** and **SETPOINT** buttons.

2. Once the red **PROG** light comes on, let go of the **ACTUAL TEMP** and **SETPOINT** buttons and use the up/down arrows to select the desired bin address.

3. Use the **PC Crown** button to confirm the selection.

NOTE: The numbering of one configuration has NO impact on the numbering of a different configuration.

Extended Hold Bin

DHB-BKF & EHB Series



Setting Bar Addresses

To allow the bin to properly communicate with the timer bar(s), bar addresses need to be correctly set as shown in the table on the previous page. This is done directly on the timer bar. First, check what the current Bar Address is by pressing and holding the Prince Castle logo button and the down arrow button until the Bar Address is shown on the far right screen of the button bar.

To change an incorrect Bar Address, follow the instructions below.



1. To change a bar address, disconnect the power to the unit. Reconnect power to the unit and immediately press and hold the **PC** button and **DOWN ARROW** buttons.



2. Once the Bar address begins to blink, release the buttons. Use the **UP/DOWN ARROWS** to select the desired bar address.



3. Use the **ENTER** button to confirm the desired Bar address.


Complete this for each button bar channel on all of the bins. Remember that button bars on the back of a unit are considered auxiliary and do not need to be separately programmed. These bars follow the programming of the bar on the front side of the same shelf.

Be sure to follow the numbering system as prescribed in the figure. The numbering of one configuration has NO impact on the numbering of a separate configuration


Loading Product Profiles

- 1 On BOH computer, Load Product Profiles for all products to be used.


Navigate to the "Product Settings" screen




- 3 After the "Warmer Type" dialogue box pops up, click on the "PC Dual Temp" tab along the top.



- 2 To load the profile for each product, double-click in the "Warmer Type" column for the product.



- 4 Select "Load Profile" from the buttons along the bottom.




Extended Hold Bin


DHB-BKF & EHB Series

Loading Product Profiles (cont.)

- 5** Find the product being programmed in the menu that pops out and click on it. Match the abbreviation shown to the product profile that is loaded.



- 6** When the menu pops back in, select "Save" .




Repeat 2-6 for all products used in the store for all Day Parts. Day Parts can be changed by clicking on the current Day Part button towards the top.
(If a product profile is loaded in one Day Part, it is not necessary to load it again in another Day Part)

Programming Holding Bins for Kitchen Use

1 Navigate to the “Program PHU” screen.



2 Change *each* section to “PC Dual Temp” from “Duke/ PC PHU” by clicking on “Duke/ PC PHU” then selecting “PC Dual Temp”.




3 Determine how the bin grouping relates to PC Minder.

For each configuration used, one row in PC Minder will be used, so start each new configuration in a new row, starting from the top. Each row represents a COM port on the Kitchen Minder (top row is COM1, middle is COM2, and bottom is COM3).

The colors in the figure to the right show which trays correspond with which boxes on PC Minder. Do not place products in the boxes that are not shaded.

The layouts to the right represent all bins except the 3x4 bins. For the specifics on how 3x4's interact with PC Minder, visit page 15.

NOTE: On a **2x3** unit, products must be placed in all four slots across in order to communicate properly with PC Minder. The products in the two bottom right shelves must match and the products on the two top right shelves must match.




Extended Hold Bin

DHB-BKF & EHB Series

Programming Holding Bins for Kitchen Use


4 Based on which configurations chosen in setup, choose products to be held in the bins. Do this by clicking anywhere in a white box and selecting the product from the dropdown menu. **IMPORTANT:** Each half of each row in a section must match, if they do not, they will display in red. Acceptable pairings will show in blue

If a tray is to be left empty, may select “-none-“.




Select a product or “-none” for each tray on all of the bins for each Day Part.

5 Save programming by selecting File > Save on the top ribbon.



6 Send Programming to Kitchen Minder by navigating to “Send to Kitchen Minder” Screen and selecting “Send Forecast”. Wait for the process is complete, it will take about 5 minutes. The Kitchen Minder should beep to validate that it is receiving data.



7 Go to bins and verify that all bars display the correct products in the correct locations, if not, check through settings in step 4 and then repeat step 6 if necessary.

8 Check that the setpoint for each Zone match what was programmed in PC Minder, , if not, check through settings in step 4 and then repeat step 6 if necessary


3x4 Special Instructions

Bin Numbering Layout

The 3x4 bins are programmed so that they can only be set to BIN2 or BIN6 because of their size.


The three possibilities are that there are (2) 3x4's, or the 3x4 is with another size bin, either first or second.

In any case, the first bin is set to BIN2 and the second is BIN6. The bars correspond to the bins like they do with the other configurations.



PC Minder Interaction

Main	PC Dual Temp PHU 1				PC Dual Temp PHU 2				PC Dual Temp PHU 3				
WHOP 240 220	WHOP 240 220	UES 250 220	UES 250 220	UES 250 220	UES 250 220	UES 250 220	UES 250 220	UES 250 220	UES 250 220	UES 250 220	UES 250 220	UES 250 220	UES 250 220
EGGS 230 200	EGGS 230 200	FTST 245 230	FTST 245 230	WHOP 240 220	WHOP 240 220	UES 250 220	UES 250 220	WHOP 240 220	WHOP 240 220	WHOP 240 220	WHOP 240 220	WHOP 240 220	WHOP 240 220



There are two options as to how 3x4 bins interact with PC Minder. On the top of the figure on the right represent s how it interacts if it is set to BIN2, and the bottom shows how it interacts if it is BIN6.

If there are two 3x4's, the middle column in PC Minder will be split between the two bins.

If another sized bin is first, it will take the first column of PC Minder, and the 3x4 will take up half of the middle column and the third column (bottom on right).

If another sized bin is second, it will take the third column of PC Minder, and the 3x4 will take up the first column and half of the second column (top on the right).